



DM1400 & DM1800 Upright Vacuum

Operating Instructions and Repair Parts List

READ THIS BOOK

This book has important information for the use and safe operation of this machine. Failure to read this book prior to operating or attempting any service or maintenance procedure to your N.A.C.E. machine could result in injury to you or to other personnel; damage to the machine or to other property could occur as well. You must have training in the operation of this machine before using it. If your operator cannot read English, have this manual explained fully before attempting to operate this machine.

Si Ud. no pueden leer el Inglés, se hagan explicar este manual completamente antes de tratar el manejo o servicio de esta máquina.

All directions given in this book are as seen from the operator's position at the rear of the machine.

For new books write to: NACECARE SOLUTIONS, 1205 Britannia Road East, Mississauga, Ontario,

Canada L4W iC7

Table of Contents

| Operator Safety Instructions | 3 |
|---------------------------------------------|----|
| Introduction & Machine Specifications | 7 |
| Grounding Instructions | 8 |
| How To Assemble The Machine | 9 |
| The Controls | 12 |
| How To Operate The Machine | 14 |
| Maintenance | 15 |
| How To Change The Filter Bag | 15 |
| How To Clean The Filter Cartridge | 16 |
| How To Replace The Brush | 16 |
| How To Change The Drive Belt | 17 |
| The Vacuum Indicator Light | 17 |
| The Circuit Breaker | 17 |
| Brush Performance Indicator Lights | 18 |
| SECTION II Parts and Service Manual | |
| Drawing #1 Upper Canister Assembly | 20 |
| Parts List #1 Upper Canister Assembly | 21 |
| Drawing #2 Brush Housing Assembly | 22 |
| Parts List #2 Brush Housing Assembly | 23 |
| Parts List #3 Hose Wand and Handle Assembly | 24 |

OPERATOR SAFETY INSTRUCTIONS

WARNING

A AVERTISSEMENT



For the safe operation of this machine, read and understand all dangers, warnings and cautions. Look for these symbols:

DANGER: If you do not follow the instructions in a **DANGER**, severe bodily injury or death can occur to

the operator and/or other personnel.

WARNING: If you do not follow the instructions in a **WARNING**, injury can occur to you or to other

personnel.

CAUTION: If you do not follow the instructions in a **CAUTION**, damage can occur to the machine.

A WARNING: To reduce the risk of fire, electric shock, or injury:

- 1. You must have training in the operation of this machine before using it. READ THE INSTRUCTION BOOK.
- 2. Do not use outdoors or on wet surfaces.
- 3. Do not leave vacuum cleaner unattended when plugged in. Turn off the switch and unplug the electrical cord when not in use and before servicing.
- 4. Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- 5. Use only as described in this manual. Use only manufacturer's recommended attachments.
- 6. Do not use with damaged cord or plug. If vacuum cleaner is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- 7. Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull a cord around sharp edges or corners. Do not run vacuum cleaner over cord. Keep cord away from heated surfaces.
- 8. Connect to a properly grounded outlet only (refer to Grounding Instructions).
- 9. Do not use extension cords or outlets with inadequate current carrying capacity.
- 10. Turn off all controls before unplugging.
- 11. Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- 12. Do not handle plug or vacuum cleaner with wet hands.
- 13. Do not put any objects into openings. Do not use with any opening blocked, keep free of dust, lint, hair, and anything that may reduce airflow.
- 14. This vacuum cleaner creates suction and contains a revolving brush. Keep hair, loose clothing, fingers and all parts of body away from openings and moving parts.
- 15. Do not pick up anything that is burning or smoking, such as cigarettes, matches or hot ashes.

WARNING: To reduce the risk of fire, electric shock, or injury:

- 16. Belt pulleys can become hot during normal use. To prevent burns, avoid touching the belt pulley when servicing the drive belt.
- 17. Do not use to pick up flammable or combustible liquids such as gasoline, or use in areas where they may be present.
- 18. Unplug the machine before servicing the belt or brush. The brush may start suddenly and cause injury.

SAVE THESE INSTRUCTIONS

CONSIGNES DE SÉCURITÈ DE L'UTILISATEUR

A AVERTISSEMENT

Pour utiliser cet appareil en toute sécurité, il faut lire et coprendre tous les consignes de danger, d'avertissement et d'attention. Soyez attentif aux symboles que voici.

 \mathbf{A}

DANGER: Ne pas respecter les consignes d'un avis de **DANGER**, peut occasionner la mort ou des

lesions corporelles graves pour l'utilisateur et/ou d'autres pesonnes.

 $oldsymbol{\Lambda}$

AVERTISSEMENT: Ne pas respecter les consignes d'un **AVERTISSEMENT** peut occasionner des lesions

corporelles pour l'utilisateur et/ou d'autres personnes.

A.

ATTENTION: Ne pas respecter les consignes d'un avis d'ATTENTION peut occasionner des dommage

à l'appareil.

AVERTISSEMENT: Pour réduire le risque de feu, de choc électrique, ou de blessure:

- Vous devez recevoir une formation appropriée avant de vous servir de cet appareil. LISEZ LE MANUEL DE CONSIGNES DU FABRICANT.
- 2. Ne pas utiliser à l'extérieur ou sur des surfaces mouillées.
- 3. Ne laissez pas l'aspirateur seul quand il est branché. Fermez le commutateur et débranchez l'appareil lorsque vous ne l'utilisez pas ou avant le nettoyage ou l'entretien.
- 4. Ne permettez pas que l'aspirateur soit utilisé comme un jouet. Une attention particulière est nécessarie lorsqu'il est utilisé par ou près d'un enfant.
- 5. Suivez strictement les recommandations d'utilisation de ce manuel. Utilisez uniquement les accessoires recommandés par le fabriquant.
- 6. N'utilisez jamais l'aspirateur si le cordon ou la fiche sont endommagés. Si l'aspirateur ne foncitionne pas comme il le devrait, s'il a été échappé, s'il est endommagé, s'il a été laissé à l'extérieur ou échappé dans l'eau, retournez-le à un centre de service avant de l'utiliser.
- 7. Ne tirez pas l'aspirateur ou le transportez par le cordon. N'utilisez pas le cordon en guise de poignée. Ne fermez pas uen porte sur le cordon ou tirez le cordon sur des bordures ou des coins pointus. Ne passez pas l'aspirateur sur le cordon. Tenez le cordon à distance des surfaces chauffantes.
- 8. Branchez toujours l'aspirateur dans une prise à trois (mise à terre).
- N'utilisez pas des rallonges ou des prises qui n'ont pas une capacité suffisante pour transporter le courant.
- 10. Mettez sur arrêt tous les boutons de commande avant de débrancher.
- 11. Ne débranchez pas l'aspirateur en tirant sur le cordon. Pour débrancher, tenez la fiche et non pas le cordon.
- 12. Ne manipulez pas la fiche ou l'aspirateur avec les mains mouillées.
- 14. N'insérez rien dans les ouvertures. N'utilisez pas l'aspirateur si des ouvertures sont bloquées. Assurez-vous qu'elles soient dégagées de poussière, de mousse, de cheveux ou de tout autre chose qui pourrait réduire le passage de l'air.
- 15. Cet aspirateur crée de la succion et contient une rouleau-brosse tournant. Tenez les parties mobiles et les ouvertures loin des cheveux, du linge, des doigts et de toute partie du corps.

AVERTISSEMENT: Pour réduire le risque de feu, de choc électrique, ou de blessure:

- 16. Ne remassez pas de objets qui brûient ou fument comme les cigarettes, les allumettes ou les cendres chaudes.
- 17. Les poulies de la courroie peuvent devenir chaudes pendant l'utilisation normale. Pour prévenir des brûlures, évitez de toucher la poulie lors de l'entretien de la courroie.
- 18. Débrancher la machine avant de faire l'entretien de la courroie ou de brosse. La brosse peut démarrer soudainement et causer des blessures.

CONSERVEZ CES INSTRUCTIONS



The DM1400 & DM1800 are upright vacuums for cleaning carpet. These machines are used to remove dry material from carpet. These machines are intended for commercial use.

MACHINE SPECIFICATIONS

| Model | DM1400 | DM1800 |
|--------------------|------------------------|------------------------|
| Power Supply | 120V-60 Cycle | 120V-60 Cycle |
| Vacuum Motor | 1050 Watts | 1050 Watts |
| Brush RPM | 4300 rpm | 4300 rpm |
| Cord | 50 ft. 3-wire | 50 ft. 3-wire |
| Wheels (2) | 2.7" x 1.25" | 2.7" x 1.25" |
| Wand | 21" extends to 33.5" | 21" extends to 33.5" |
| Hose | 1.5" x 18.5" | 1.5" x 18.5" |
| | extends to 72" | extends to 72" |
| Agitator Brush | Chevron Brush Pattern | Chevron Brush Pattern |
| Cleaning Width | 14" | 18" |
| Filter Bags | 6 lt, 2-ply disposable | 6 lt, 2-ply disposable |
| Weight (less power | | |
| cord) | 20 lbs. | 20.5 lbs. |
| Shipping Weight | 26 lbs | 26.75 lbs |
| Vacuum Dimensions | 10.5 x 14.25 x 46.5 | 10.5 x 14.25 x 46.5 |
| Warranty | One Year | One Year |

GROUNDING INSTRUCTIONS

Preparation:

The following are instructions for connection to the power supply and the electrical ground.

This machine must be connected to the electrical ground to protect the operator from electrical shock. The machine has an approved power cord with three conductors and a plug with three terminals. Connect the plug to a receptacle that has three holes and is connected to the electrical ground. The green (or green and yellow) conductor in the cord is the ground wire. Never connect this wire to any terminal other than the ground pin terminal.



A DANGER: Improper connection of

the equipment-grounding conductor can result in risk of electric shock. Check with a qualified electrician or service person if you are in doubt as to whether the outlet is properly grounded. Do not modify the plug provided with the appliance. If it will not fit the outlet, have a proper outlet installed by a qualified electrician.

This machine is for use on a 110 to 120 Volt AC 60 cycle electric circuit. Make sure you have the correct frequency and voltage before connecting the power cord to an outlet. The machine has a plug as shown in figure A.



WARNING: Always use this machine with an AC three-conductor electrical system connected to the electrical ground. Replace any worn, cut or damaged cords. Replace any damaged plugs, receptacles or connector bodies.



WARNING: Do not cut, remove, or break the ground terminal. Do not try to fit a three-terminal plug into a receptacle or connector body that does not fit the plug, see your Authorized N.A.C.E. Dealer to get an authorized person to make the connection.




WARNING: Do not move the machine over an electrical cord. Always lift the cord over the machine.

EXTENSION CORDS:

Use only an approved extension cord with three conductors, a plug with three terminals and a connector body with three holes. This machine has a power cord with wire size 18 AWG (AWG means American Wire Gauge).



WARNING: If you use an extension cord, use an extension cord with minimum wire size 16 AWG. Do not use an extension cord longer than 50 feet. Do not join two extension cords.



INSTRUCTIONS VISANT LA MISE A LA TERRE

PREPARATION:

Consignes pour brancher l'appareil a la source d'energie et pour la mise à la terre.

Cet appareil doit être mise à la terre afin d'eviter le risque de choc électrique. Cet appareil est pourvu d'un cordon muni de trois conducteurs et d'une fiche munie de trois bornes. Brancher la fiche à une prise qui a trois tous et est mise à la terre. Le conducteur vert (ou vert et jaune) dans le cordon est le fil neutre. Ne jamais attacher ce conducteur à une borne autre que la borne à terre.



A DANGER: Un conducteur de terre

mal raccordé peut entraîner un risque de choc électrique. Consulter un electricien ou un technicien qualifié si vous n'êtes pas certain que la prise est correctement mise à la terre. Ne pas modifier la fiche fournie avec l'appareil. Si elle ne peut être insérée dans la prise, faire installer une prise adéquate par un électricien qualifié.

Cet appareil est destiné à un circuit de 110 à 120 volts et 60 cycles. S'assurer que l'appareil est branché à une prise de courant ayant la même configuration que la fiche. Cet appareil est muni d'une fiche de mise à la terre semblable à celle illustrée par la Figure A.



AVERTISSEMENT: Toujours employer cet appareil avec un système électrique AC à trois conducteurs, raccordé à la mise à la terre. Remplacer tout cordon usé, coupé ou endommagé. Remplacer toute fiche ou prise endommagée.



AVERTISSEMENT: Ne pas couper, briser, ou enlever la prise de terre. Ne pas chercher à brancher la fiche à trois bornes, à une prise que ne lul correspond pas. Si la prise ne correspond pas à la fiche, contacter votre agent de vente autorisé des appareils N.A.C.E. afin qu'une personne qualifiée effectue le branchement.




AVERTISSEMENT: Ne pas faire passer l'appareil sur le cordon électrique. Soulever toujours le cordon pour faire passer l'appareil en dessous.

LES RALLONGES:

Utilise seulement une rallonge approuvée à trois fils conducteurs, munie d'une fiche à trois bornes et d'une prise à trois trous. Cet appareil est muni d'un cordon électrique dont les fils sont de calibre 16 AWG (AWG signifie American Wire Gauge).



AVERTISSEMENT: Si vous utilisez une rallonge, celle-ci doit avoir un calibre de fil minimum de 16 AWG. Ne pas utiliser de rallonge qui dépasse 50 pieds (15 mètres) de long. Ne pas raccorder deux rallonges ensemble.



Note: Au Canada, l'utilisation d'un adaptateur temporaire n'est pas autorisée par le Code canadien de l'électricité.

HOW TO ASSEMBLE THE MACHINE

To assemble the machine, follow this procedure:

- Remove the brush housing, vacuum bags, hose, wand, handle assembly, canister housing, and tools from the carton.
- 2. Remove the canister housing and the brush housing from the plastic bags.
- Install the canister housing on the brush housing. To install the canister housing, follow this procedure:
 - a. Position canister housing over brush housing (see figure 2).
 - b. Align pivot airway (A) and canister support pivot (B) with openings (C and D) in bottom of canister housing (see figure 2).
 - c. Lower canister housing completely onto brush housing until pin clicks into place and latches (see figure 3).
- 4. Install the handle assembly to the canister housing. To install the handle assembly, follow this procedure:
 - a. Insert handle tube in the upper canister housing (see figure 4).
 - Lower handle completely into canister housing until mark on handle tube is below flush (see figure 5, item A). This insures the handle is properly seated.
 - c. Push handle latch into lock position (see figure 5, item B).




Figure 5




Figure 2




Figure 3




Figure 4

- 5. Install the wand assembly in the right rear canister housing (see figure 6, item A).
- 6. Position wand handle so that handle is towards the front of the machine (see figure 7, item A).
- 7. Attach hose to wand and canister (see figure 7).

 To attach hose properly, depress lock on canister (see figure 7, item B).
- 8. Snap the crevice (B) and upholstery (C) tools into the tool retainer on rear of canister housing (see figure 6).




Figure 6




Figure 7

THE CONTROLS

The Handle Release Pedal (See figure 8, item A)

The handle release pedal is on the lower left side of the machine. Press the pedal to release the handle and start the brush motor. The brush motor will not run unless the ON/OFF switch is in the "I" position.

The ON/OFF Switch (See figure 9)

The ON/OFF switch is on handle. Put the switch in the "I" position to start the vacuum motor. Put the switch in the "O" position to stop the vacuum motor. Putting the switch in the off position will also shut off the brush motor

The Height Adjustment (See figure 8, item B)

The height adjustment is located on the lower right side of the machine. Press the front of the pedal with your foot when vacuuming shorter carpet. Press the back of the pedal with your foot when vacuuming thicker, longer carpet.

The Wand (See figure 8, item C)

The wand is in the holder in the back of the canister housing. The wand has a telescoping feature (see figure 11). The crevice tool and the upholstery tools fit the end of the wand. The wand has a suction control sleeve (see figure 10). For normal vacuuming keep suction control sleeve closed. To reduce suction, when cleaning drapes or furniture, open suction control sleeve.




Figure 11




Figure 8




Figure 9




Figure 10

Canister Door (See figure 12, item A)

The canister door release is in the upper part of the canister housing. Lift to open door.

NOTE: Door will not close without a properly mounted filter bag. See page 11 for filter bag mounting instructions.

The Vacuum Indicator Light (See figure 12, item B)

The vacuum indicator light is on the top of the canister housing. The indicator light comes on when the airflow to the vacuum motor is obstructed.

NOTE: See page 17 for instructions on how to remove an obstruction.

The Cord Storage Hooks (See figure 13)

The cord storage hooks are on the back of the canister housing. The lower cord hook is also a carrying handle. The lower cord hook rotates to provide a quick cord release and to ease cord removal.




Figure 12




Figure 13

HOW TO OPERATE THE MACHINE



CAUTION: To prevent damage to the machine, do not allow large objects to be pulled into the lower housing or the attachments.

NOTE: The machine comes with a filter bag installed in the canister housing.

Use the DM1400 & DM1800 as a carpet cleaner or as an upholstery cleaner. To operate the machine as a carpet cleaner, follow this procedure:

- 1. Remove the power cord from the cord storage hooks, by rotating the lower cord hook 180° (see figure 14).
- 2. Connect the electrical plug to the electrical outlet.
- 3. Put the ON/OFF switch in the "I" position (see figure 9).
- 4. Press the handle release pedal (see figure 8, item A).
- 5. Pull the handle toward you to the best operating position.
- 6. Move the machine forward and backward over the carpet.

To operate the machine as an upholstery cleaner, follow this procedure.

- Make sure the ON/OFF switch is in the "O" position.
- 2. Push the handle forward until it locks in position.

NOTE: the machine comes with a crevice tool attachment and an upholstery tool attachment. Select the tool needed for the cleaning operation.

- 3. Remove the wand from the canister housing.
- 4. Connect an accessory tool to the end of the wand, or directly to the hose (see figures 15 and 16).

NOTE: Push button on wand handle to release the hose from the wand (see figure 16, item A).

- 5. Put the ON/OFF switch in the "I" position.
- 6. Move the tool over the area to be cleaned.




Figure 14




Figure 15




Figure 16

MAINTENANCE



WARNING: To prevent injury, always remove the electrical plug from the electrical outlet before doing any maintenance or repairs to the machine.



WARNING: Maintenance and repairs must be done by authorized personnel only. Use only genuine N.A.C.E. parts.

How To Change The Filter Bag

The machine uses a disposable paper filter bag. To change the paper filter bag, follow this procedure:

- 1. Make sure the ON/OFF switch in the "O" position and that the machine is disconnected from the power supply.
- 2. Open the front of the canister housing. To open the canister housing, lift the release handle (see figure 17).
- 3. Grasp cardboard inlet on both sides of the bag (see points A and B on figure 19) and slightly rotate and pull bag out.
- 5. Install a new filter bag. To install a new filter bag, follow this procedure:
 - a. Unfold the filter bag.
 - b. Hold the bag by the cardboard inlet.
 - Place the bottom of the cardboard inlet into the slot under the bag adaptor (see figure 18, item A)
 - d. Put the opening of the cardboard inlet over the bag adapter (see figure 18, item B).
 - e. Make sure the cardboard is pushed all the way on the bag adapter (figure 19) or the door will not latch.
 - f. Close the canister housing.




Figure 17




Figure 18




Figure 19

How To Change The Filter Cartridge

Change the filter cartridge whenever it is dirty or suction performance decreases. To change the filter cartridge, follow this procedure:

- Make sure the ON/OFF switch is in the "O" position and the machine is disconnected from the power supply.
- 2. Open the canister door.
- 3. Remove the filter bag.
- 4. Remove the filter cartridge (see figure 20).
- 5. Replace filter cartridge and filter bag (see figure 21).



CAUTION: Check the filter cartridge while changing the paper bag. Replace the filter cartridge when dirty or when the vacuum suction performance drops off even with a clean filter bag.

How To Replace The Brush



WARNING: To prevent injury, unplug machine before cleaning or replacing brush. Brush may start suddenly and cause injury.

- 1. Put the machine on its side.
- 2. Turn the knobs which secure the nozzle plate. See figure 22.
- 3. Lift the nozzle plate up to remove it.
- 4. Lift the brush assembly up to remove it.
- 5. Install the new brush assembly.
- 6. Install the nozzle plate.
- 7. Put the machine on its wheels.



WARNING: To reduce the risk of injury from moving parts, unplug before servicing.




Figure 20




Figure 21




Figure 22

How To Change the Drive Belt



WARNING: To prevent injury, unplug machine before cleaning or replacing brush. Brush may start suddenly and cause injury.

To change the drive belt, follow this procedure:

- 1. Put the machine on its side.
- 2. Lift the nozzle plate up to remove it.
- 3. Lift the brush assembly up to remove it (see figure 23).
- 4. Remove the drive belt from the brush pulley.
- 5. Remove the drive belt from the motor shaft.
- Put one end of the new drive belt around the motor shaft.
- 7. Put the other end of the drive belt around the brush pulley.
- 8. Install the brush assembly in the brush housing.
- 9. Install the nozzle plate.
- 10. Put the machine on its wheels.



WARNING: To reduce the risk of injury from moving parts, unplug before servicing.

The Vacuum Indicator Light

If the vacuum indicator light (1) comes on, (see figure 24) or the motor stops, do the following:

- 1. Put the ON/OFF switch in the "O" position (2).
- Remove the electrical plug from the electrical outlet.
- 3. Check the vacuum hose for an obstruction. If there is an obstruction in the vacuum hose, remove the obstruction.
- Check the brush assembly in the lower housing. If there is an obstruction in the brush assembly, remove the obstruction.
- 5. Check the filter bag. If the filter bag is over 1/2 full, change or empty the bag.
- 6. Check the filter cartridge. If the filter is dirty, change the filter.

Thermal Overload

A thermal overload is used to protect the vacuum motor. If the motor over heats, the thermal overload will stop the motor. If the motor stops, let the motor cool before restarting the machine. Check filters. If the motor continues to stop, consult an authorized service person.




Figure 23




Figure 24

BRUSH PERFORMANCE INDICATOR LIGHTS

The UTV14 & UTV18 upright vacuums have 3 brush performance indicator lights (see figure 25). They are <u>GREEN</u>, <u>YELLOW</u> and <u>RED</u>. They work in the following manner:

Normal Operation:

 The GREEN light is on when the brush drive motor is on and the brush height setting is correct for the carpet.

NOTE: It is normal for the red or yellow light to intermittently turn on and off as high or low surfaces are encountered.

Brush Height Too High:

 The YELLOW light will continue to stay on when the brush height is too high for the carpet. Lower the brush height setting.

Brush Height Too Low or Brush Has Jammed:

- The RED light will continue to stay on when the brush height setting is too low for the carpet. Raise the brush height setting. The RED light will come on if the brush is jammed.
- If the RED light is on continuously for 10 seconds, the electronic safety stop will protect the brush motor by turning it off.
- To reset the brush drive motor, put the operating handle in the upright position. Turn the ON/OFF switch to the off position. Restart the machine.
- If the brush height was too low, raise the brush height setting.
- If the brush was jammed, unplug the vacuum and clear the brush.





Figure 25

DM1400 & DM1800 Upright Vacuum Repair Parts List

N.A.C.E.

DM1400 & DM1800

Drawing #1 Upper Canister Assembly 3/04




N.A.C.E. DM1400 & DM1800

Parts List #1 Upper Canister Assembly 3/04

| 1 53296A Handle Tube 1 1A 53199N Handle, Left 1 1B 53207N Handle, Right 1 1C 53320A On/Off Switch 1 1D 53315A Pad. Soft Touch 1 1E 53318A Power Cord 1 1F 53233A Receptacle, Handle 1 2 53211N Canister, Rear 1 (incl. #4, 5, 6, 7, 28, 29, 30, 35, 36) Plug, Canister 1 4 53257A Plvot, Filter Baq Asm. 1 5 53347A Screw, M4 x 16 24 6 53213A Adaptor, Air Inlet Asm. 1 (incl. gaskets - 53307A & 53308A) 1 1 7 53258A Guide, Bag Collar 1 8 53212A Cover, WDoor Latch 1 9 53430A Bag, Paper (pkg. 10) 1 10 53273A Gasket, Door 1 11 53218N Door, Asm. Canister | Ref. No. | Part No. | Description | No. Req'd. |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------|----------|-----------------------------------------|---------------|
| 1A 53199N Handle, Left 1 1B 53207N Handle, Right 1 1C 53320A On/Off Switch 1 1D 53315A Pad. Soft Touch 1 1E 53318A Power Cord 1 1F 53233A Receptacle, Handle 1 2 53211N Canister, Rear 1 (incl. #4, 5, 6, 7, 28, 29, 30, 35, 36) 1 3 53234A Plug, Canister 1 4 53257A Pivot, Filter Bag Asm. 1 5 53347A Screw, M4 x 16 24 6 53213A Adaptor, Air Inlet Asm. 1 (incl. gaskets - 53307A & 53308A) Guide, Bag Collar 1 7 53258A Guide, Bag Collar 1 8 53212A Cover, WDoor Latch 1 9 53430A Bag. Paper (pkg. 10) 1 10 53273A Gasket, Door 1 11 53218N Door, Asm. Canister | 1 1 | 53296A | Handle Tube | l 1 |
| 1B 53207N Handle, Right 1 1C 53320A On/Off Switch 1 1D 53315A Pad, Soft Touch 1 1E 53318A Power Cord 1 1F 53233A Receptacle, Handle 1 2 53211N Canister, Rear (incl. #4, 5, 6, 7, 28, 29, 30, 35, 36) 1 3 53234A Plug, Canister 1 4 53257A Pivot, Filter Bag Asm. 1 5 53347A Screw, M4 x 16 24 6 53213A Adaptor, Air Inlet Asm. (incl. gaskets - 53307A & 53308A) 1 7 53258A Guide, Bag Collar 1 8 53212A Cover, w/Door Latch 1 9 53430A Bag, Paper (pkg, 10) 1 10 53273A Gasket, Door 1 11 53218N Door, Asm. Canister 1 (incl. #10, 12 & 13) Spring, Door Catch 2 12 53330A Spring, Door Catch 2 | 1 A | 53199N | | |
| 1C | 1B | | | l 1 |
| 1D | 1C | | , , | l 1 |
| 1E 53318A Power Cord 1 1F 53233A Receptacle, Handle 1 2 53211N Canister, Rear 1 (incl. #4, 5, 6, 7, 28, 29, 30, 35, 36) 1 3 53234A Plug, Canister 1 4 53257A Pivot, Filter Bag Asm. 1 5 53347A Screw, M4 x 16 24 6 53213A Adaptor, Air Inlet Asm. 1 (incl. gaskets - 53307A & 53308A) 1 1 7 53258A Guide, Bag Collar 1 8 53212A Cover, W/Door Latch 1 9 53430A Bag, Paper (pkg. 10) 1 10 53273A Gasket, Door 1 11 53218N Door, Asm. Canister 1 10 53219N Latch, Canister Door 1 14 53219N Latch, Canister Door 1 15 5330A Exhaust Filter 1 16 53217N Cover, Sy Dough Motor | | | | l i l |
| 1F 53233A Receptacle, Handle 1 2 53211N Canister, Rear 1 (incl. #4, 5, 6, 7, 28, 29, 30, 35, 36) 1 3 53234A Plug, Canister 1 4 53257A Pivot, Filter Bag Asm. 1 5 53347A Screw, M4 x 16 24 6 53213A Adaptor, Air Inlet Asm. 1 (incl. gaskets - 53307A & 53308A) 1 1 7 53258A Guide, Bag Collar 1 8 53212A Cover, w/Door Latch 1 9 53430A Bag, Paper (pkg. 10) 1 10 53273A Gasket, Door 1 11 53218N Door, Asm. Canister 1 12 53330A Spring, Door Catch 2 13 53219N Latch, Canister Door 1 14 5321N Cover, Asm. Vac Motor 1 15 53302A Exhaust Filter 1 16 53217N Cover, Sw. Vac Woto | 1E | | | 1 |
| (incl. #4, 5, 6, 7, 28, 29, 30, 35, 36) Plug, Canister 1 4 53257A Plug, Canister 1 24 53257A Screw, M4 x 16 24 6 53213A Adaptor, Air Inlet Asm. (incl. gaskets - 53307A & 53308A) 7 53258A Guide, Bag Collar 1 53218A Gasket, Door Latch 9 53430A Bag, Paper (pkg. 10) 1 1 53218N Door, Asm. Canister (incl. #10, 12 & 13) 12 53330A Spring, Door Catch 2 13 53219N Latch, Canister Door 1 14 53215N Cover, Asm. Vac Motor 1 15 53302A Exhaust Filter 1 1 16 53217N Cover, Exhaust Filter 1 1 17 53266A Cover, 2 pc. Vac Motor 1 19 53324A Motor, Vacuum Motor 1 19 53324A Motor, Vacuum 120V 1 (incl. des # 53356A) Same as 17 - 2pc. Set 1 2 53300A Filter Cartridge 1 1 1 1 1 1 1 1 1 | 1F | 53233A | | 1 |
| 3 53234A Plug, Canister 1 4 53257A Pivot, Filter Baq Asm. 1 5 53347A Screw, M4 x 16 24 6 53213A Adaptor, Air Inlet Asm. 1 (incl. gaskets - 53307A & 53308A) 1 1 7 53258A Guide, Bag Collar 1 8 53212A Cover, w/Door Latch 1 9 53430A Bag, Paper (pkg. 10) 1 10 53273A Gasket, Door 1 11 53218N Door, Asm. Canister 1 11 53218N Spring, Door Catch 2 13 53219N Latch, Canister Door 1 14 53215N Cover, Asm. Vac Motor 1 15 53302A Exhaust Filter 1 16 53217N Cover, Exhaust Filter 1 17 53266A Cover, 2 pc. Vac Motor 1 18 53271A Spacer, Vacuum Motor 1 19 53324 | 2 | 53211N | Canister, Rear | 1 1 |
| 4 53257A Pivot, Filter Bag Asm. 1 5 53347A Screw, M4 x 16 24 6 53213A Adaptor, Air Inlet Asm. 1 (incl. gaskets - 53307A & 53308A) 1 7 53258A Guide, Bag Collar 1 8 53212A Cover, w/Door Latch 1 9 53430A Bag, Paper (pkg, 10) 1 10 53273A Gasket, Door 1 11 53218N Door, Asm. Canister 1 11 53218N Spring, Door Catch 2 13 53219N Latch, Canister Door 1 14 53215N Cover, Asm. Vac Motor 1 15 53302A Exhaust Filter 1 16 53217N Cover, Exhaust Filter 1 17 53266A Cover, 2 pc. Vac Motor 1 18 53271A Spacer, Vacuum Motor 1 19 53324A Motor, Vacuum 120V 1 10 (incl.des # 53356A) | | | (incl. #4, 5, 6, 7, 28, 29, 30, 35, 36) | |
| 5 53347A Screw, M4 x 16 24 6 53213A Adaptor, Air Inlet Asm. (incl. gaskets - 53307A & 53308A) 1 7 53258A Guide, Bag Collar 1 8 53212A Cover, w/Door Latch 1 9 53430A Bag, Paper (pkg. 10) 1 10 53273A Gasket, Door 1 11 53218N Door, Asm. Canister (incl. #10, 12 & 13) 12 53330A Spring, Door Catch 2 13 53219N Latch, Canister Door 1 14 53215N Cover, Asm. Vac Motor 1 15 53302A Exhaust Filter 1 16 53217N Cover, Exhaust Filter 1 17 53266A Cover, 2 pc. Vac Motor 1 18 53271A Spacer, Vacuum Motor 1 19 53324A Motor, Vacuum 120V 1 10 (includes # 53356A) Same as 17 - 2pc. Set 1 21 53270A Endcap, Vac Motor | 3 | 53234A | Plug, Canister | 1 |
| 6 53213A Adaptor, Air Inlet Asm. (incl. gaskets - 53307A & 53308A) 1 7 53258A Guide, Bag Collar Cover, w/Door Latch 1 9 53430A Bag, Paper (pkg. 10) 1 10 53273A Gasket, Door 1 11 53218N Door, Asm. Canister (incl. #10, 12 & 13) 1 12 53330A Spring, Door Catch 2 13 53219N Latch, Canister Door 1 14 53215N Cover, Asm. Vac Motor 1 15 53302A Exhaust Filter 1 16 53217N Cover, Exhaust Filter 1 17 53266A Cover, 2 pc. Vac Motor 1 18 53271A Spacer, Vacuum Motor 1 19 53324A Motor, Vacuum 120V 1 19 53324A Motor, Vacuum 120V 1 20 Same as 17 - 2pc. Set 1 21 53270A Endcap, Vac Motor 1 22 53300A Filter Cartridge | 4 | 53257A | Pivot, Filter Bag Asm. | 1 |
| 7 53258A (incl. gaskets - 53307A & 53308A) 8 53212A Cover, w/Door Latch 1 9 53430A Bag, Paper (pkg. 10) 1 10 53273A Gasket, Door 1 11 53218N Door, Asm. Canister 1 11 53218N Door, Asm. Canister 1 11 53219N Latch, Canister Door 1 14 53215N Cover, Asm. Vac Motor 1 14 53215N Cover, Asm. Vac Motor 1 15 53302A Exhaust Filter 1 16 53217N Cover, Exhaust Filter 1 17 53266A Cover, 2 pc. Vac Motor 1 18 53271A Spacer, Vacuum Motor 1 19 53324A Motor, Vacuum 120V 1 19 53324A Motor, Vacuum Motor 1 20 Same as 17 - 2pc. Set 1 21 53270A Endcap, Vac Motor 1 22 53306A | 5 | 53347A | Screw, M4 x 16 | 24 |
| 7 53258A Guide, Bag Collar 1 8 53212A Cover, w/Door Latch 1 9 53430A Bag, Paper (pkg. 10) 1 10 53273A Gasket, Door 1 11 53218N Door, Asm. Canister 1 11 53218N Door, Asm. Canister 1 12 53330A Spring, Door Catch 2 13 53219N Latch, Canister Door 1 14 53215N Cover, Asm. Vac Motor 1 15 53302A Exhaust Filter 1 16 53217N Cover, Exhaust Filter 1 16 53217N Cover, Exhaust Filter 1 17 53266A Cover, 2 pc. Vac Motor 1 18 53271A Spacer, Vacuum Motor 1 19 53324A Motor, Vacuum 120V 1 (includes # 53356A) Same as 17 - 2pc. Set 1 21 53270A Endcap, Vac Motor 1 22 | 6 | 53213A | Adaptor, Air Inlet Asm. | 1 |
| 8 53212A Cover, w/Door Latch 1 9 53430A Bag, Paper (pkg. 10) 1 10 53273A Gasket, Door 1 11 53218N Door, Asm. Canister 1 (incl. #10, 12 & 13) 12 53330A Spring, Door Catch 2 13 53219N Latch, Canister Door 1 14 53215N Cover, Asm. Vac Motor 1 14 53217N Cover, Asm. Vac Motor 1 16 53217N Cover, Exhaust Filter 1 17 53266A Cover, 2 pc. Vac Motor 1 18 53271A Spacer, Vacuum Motor 1 19 53324A Motor, Vacuum 120V 1 (includes # 53356A) Same as 17 - 2pc. Set 1 21 53270A Endcap, Vac Motor 1 22 53300A Filter Cartridge 1 23 53256A Channel, Airway Asm. 1 (incl. receptacle) 1 Saund Insulation Set | | | (incl. gaskets - 53307A & 53308A) | |
| 9 | 7 | 53258A | Guide, Bag Collar | 1 |
| 10 53273A Gasket, Door 1 11 53218N Door, Asm. Canister (incl. #10, 12 & 13) 12 53330A Spring, Door Catch 2 13 53219N Latch, Canister Door 1 14 53215N Cover, Asm. Vac Motor 1 15 53302A Exhaust Filter 1 16 53217N Cover, Exhaust Filter 1 17 53266A Cover, 2 pc. Vac Motor 1 18 53271A Spacer, Vacuum Motor 1 19 53324A Motor, Vacuum 120V 1 (includes # 53356A) Same as 17 - 2pc. Set 1 21 53270A Endcap, Vac Motor 1 22 53300A Filter Cartridge 1 23 53256A Channel, Airway Asm. 1 (incl. receptacle) 1 24 53306A Sound Insulation Set 1 25 53214A Latch, Canister to Brush Hsg. 1 26 53274A Pi | 8 | 53212A | Cover, w/Door Latch | 1 |
| 11 53218N Door, Asm. Canister (incl. #10, 12 & 13) 12 53330A Spring, Door Catch 2 13 53219N Latch, Canister Door 1 14 53215N Cover, Asm. Vac Motor 1 15 53302A Exhaust Filter 1 16 53217N Cover, Exhaust Filter 1 17 53266A Cover, 2 pc. Vac Motor 1 18 53271A Spacer, Vacuum Motor 1 19 53324A Motor, Vacuum 120V 1 19 53324A Motor, Vacuum 120V 1 20 Same as 17 - 2pc, Set 1 21 53270A Endcap, Vac Motor 1 22 53300A Filter Cartridge 1 23 53256A Channel, Airway Asm. 1 24 53306A Sound Insulation Set 1 25 53214A Latch, Canister to Brush Hsg. 1 26 53274A Pin, Canister to Brush Hsg. 1 27 </td <td>9</td> <td>53430A</td> <td>Bag, Paper (pkg. 10)</td> <td>1</td> | 9 | 53430A | Bag, Paper (pkg. 10) | 1 |
| 12 | 10 | 53273A | Gasket, Door | 1 |
| 12 53330A Spring, Door Catch 2 13 53219N Latch, Canister Door 1 14 53215N Cover, Asm. Vac Motor 1 15 53302A Exhaust Filter 1 16 53217N Cover, Exhaust Filter 1 17 53266A Cover, 2 pc. Vac Motor 1 18 53271A Spacer, Vacuum Motor 1 19 53324A Motor, Vacuum 120V 1 19 53324A Motor, Vacuum 120V 1 20 Same as 17 - 2pc. Set 1 21 53270A Endcap, Vac Motor 1 22 53300A Filter Cartridge 1 23 53256A Channel, Airway Asm. 1 (incl. receptacle) 1 1 24 53306A Sound Insulation Set 1 25 53214A Latch, Canister to Brush Hsg. 1 27 53319A Interconnect Cord (incl. #43) 1 28 53240A <td>11</td> <td>53218N</td> <td></td> <td>1</td> | 11 | 53218N | | 1 |
| 13 53219N Latch, Canister Door 1 14 53215N Cover, Asm. Vac Motor 1 (incl. # 25 & 26) 1 1 15 53302A Exhaust Filter 1 16 53217N Cover, Exhaust Filter 1 17 53266A Cover, 2 pc. Vac Motor 1 18 53271A Spacer, Vacuum Motor 1 19 53324A Motor, Vacuum 120V 1 20 Same as 17 - 2pc. Set 1 21 53270A Endcap, Vac Motor 1 22 53300A Filter Cartridge 1 23 53256A Channel, Airway Asm. 1 24 53306A Sound Insulation Set 1 25 53214A Latch, Canister to Brush Hsg. 1 26 53274A Pin, Canister to Brush Hsg. 1 27 53319A Interconnect Cord (incl. #43) 1 28 5328A Spring, Air Valve 1 29 5324 | | | (incl. #10, 12 & 13) | |
| 14 53215N Cover, Asm. Vac Motor (incl. # 25 & 26) 15 53302A Exhaust Filter 1 16 53217N Cover, Exhaust Filter 1 17 53266A Cover, 2 pc. Vac Motor 1 18 53271A Spacer, Vacuum Motor 1 19 53324A Motor, Vacuum 120V 1 20 Same as 17 - 2pc. Set 1 21 53270A Endcap, Vac Motor 1 22 53300A Filter Cartridge 1 23 53256A Channel, Airway Asm. 1 24 53306A Sound Insulation Set 1 25 53214A Latch, Canister to Brush Hsg. 1 26 53274A Pin, Canister to Brush Hsg. 1 27 53319A Interconnect Cord (incl. #43) 1 28 53328A Spring, Air Valve 1 29 53240A Plunger, Spring 1 30 53254A Retainer, Air Valve 1 31 | 12 | 53330A | Spring, Door Catch | 2 |
| 15 53302A Exhaust Filter 1 16 53217N Cover, Exhaust Filter 1 17 53266A Cover, 2 pc. Vac Motor 1 18 53271A Spacer, Vacuum Motor 1 19 53324A Motor, Vacuum 120V 1 20 Same as 17 - 2pc. Set 1 21 53270A Endcap, Vac Motor 1 22 53300A Filter Cartridge 1 23 53256A Channel, Airway Asm. 1 24 53306A Sound Insulation Set 1 25 53214A Latch, Canister to Brush Hsg. 1 26 53274A Pin, Canister to Brush Hsg. 1 27 53319A Interconnect Cord (incl. #43) 1 28 53328A Spring, Air Valve 1 29 53240A Plunger, Spring 1 30 53264A Retainer, Air Valve 1 31 53252A Retainer, Tools 1 32 | 13 | 53219N | , | 1 |
| 15 53302A Exhaust Filter 1 16 53217N Cover, Exhaust Filter 1 17 53266A Cover, 2 pc. Vac Motor 1 18 53271A Spacer, Vacuum Motor 1 19 53324A Motor, Vacuum 120V 1 20 Same as 17 - 2pc. Set 1 21 53270A Endcap, Vac Motor 1 22 53300A Filter Cartridge 1 23 53256A Channel, Airway Asm. 1 24 53306A Sound Insulation Set 1 25 53214A Latch, Canister to Brush Hsg. 1 26 53274A Pin, Canister to Brush Hsg. 1 27 53319A Interconnect Cord (incl. #43) 1 28 53328A Spring, Air Valve 1 29 53240A Plunger, Spring 1 30 53264A Retainer, Air Valve 1 31 53252A Retainer, Tools 1 32 | 14 | 53215N | Cover, Asm. Vac Motor | 1 |
| 16 53217N Cover, Exhaust Filter 1 17 53266A Cover, 2 pc. Vac Motor 1 18 53271A Spacer, Vacuum Motor 1 19 53324A Motor, Vacuum 120V 1 20 Same as 17 - 2pc. Set 1 21 53270A Endcap, Vac Motor 1 22 53300A Filter Cartridge 1 23 53256A Channel, Airway Asm. 1 (incl. receptacle) Sound Insulation Set 1 24 53306A Sound Insulation Set 1 25 53214A Latch, Canister to Brush Hsg. 1 26 53274A Pin, Canister to Brush Hsg. 1 27 53319A Interconnect Cord (incl. #43) 1 28 53328A Spring, Air Valve 1 29 53240A Plunger, Spring 1 30 53264A Retainer, Air Valve 1 31 53252A Retainer, Tools 1 32 | | | (incl. # 25 & 26) | |
| 17 53266A Cover, 2 pc. Vac Motor 1 18 53271A Spacer, Vacuum Motor 1 19 53324A Motor, Vacuum 120V 1 20 Same as 17 - 2pc. Set 1 21 53270A Endcap, Vac Motor 1 22 53300A Filter Cartridge 1 23 53256A Channel, Airway Asm. 1 (incl. receptacle) Channel, Airway Asm. 1 24 53306A Sound Insulation Set 1 25 53214A Latch, Canister to Brush Hsg. 1 26 53274A Pin, Canister to Brush Hsg. 1 27 53319A Interconnect Cord (incl. #43) 1 28 53328A Spring, Air Valve 1 29 53240A Plunger, Spring 1 30 53264A Retainer, Air Valve 1 31 53252A Retainer, Tools 1 32 53220N Crevice Tool 1 34 <t< td=""><td>15</td><td>53302A</td><td>Exhaust Filter</td><td>1</td></t<> | 15 | 53302A | Exhaust Filter | 1 |
| 18 53271A Spacer, Vacuum Motor 1 19 53324A Motor, Vacuum 120V 1 20 Same as 17 - 2pc. Set 1 21 53270A Endcap, Vac Motor 1 22 53300A Filter Cartridge 1 23 53256A Channel, Airway Asm. 1 (incl. receptacle) 1 1 24 53306A Sound Insulation Set 1 25 53214A Latch, Canister to Brush Hsg. 1 26 53274A Pin, Canister to Brush Hsg. 1 27 53319A Interconnect Cord (incl. #43) 1 28 53328A Spring, Air Valve 1 29 53240A Plunger, Spring 1 30 53264A Retainer, Tools 1 31 53252A Retainer, Tools 1 32 53220N Crevice Tool 1 33 53251N Upholstery Tool w/Brush 1 34 53253A | | 53217N | · | |
| 19 53324A Motor, Vacuum 120V (includes # 53356A) 1 20 Same as 17 - 2pc. Set 1 21 53270A Endcap, Vac Motor 1 22 53300A Filter Cartridge 1 23 53256A Channel, Airway Asm. 1 (incl. receptacle) Sound Insulation Set 1 24 53306A Sound Insulation Set 1 25 53214A Latch, Canister to Brush Hsg. 1 26 53274A Pin, Canister to Brush Hsg. 1 27 53319A Interconnect Cord (incl. #43) 1 28 53328A Spring, Air Valve 1 29 53240A Plunger, Spring 1 30 53264A Retainer, Air Valve 1 31 53252A Retainer, Tools 1 32 53220N Crevice Tool 1 33 53251N Upholstery Tool w/Brush 1 34 53253A Handle, Cord Hook 1 | | | | |
| (includes # 53356A) 20 | 1 1 | | | |
| Same as 17 - 2pc. Set 1 | 19 | 53324A | • | 1 |
| 21 53270A Endcap, Vac Motor 1 22 53300A Filter Cartridge 1 23 53256A Channel, Airway Asm. 1 (incl. receptacle) 1 24 53306A Sound Insulation Set 1 25 53214A Latch, Canister to Brush Hsg. 1 26 53274A Pin, Canister to Brush Hsg. 1 27 53319A Interconnect Cord (incl. #43) 1 28 53328A Spring, Air Valve 1 29 53240A Plunger, Spring 1 30 53264A Retainer, Air Valve 1 31 53252A Retainer, Tools 1 32 53220N Crevice Tool 1 33 53221N Upholstery Tool w/Brush 1 34 53253A Handle, Cord Hook 1 36 53254N Swivel, Cord Hook 1 37 53255A Retainer, Hose 2 38 53290N <t< td=""><td></td><td></td><td>,</td><td></td></t<> | | | , | |
| 22 53300A Filter Cartridge 1 23 53256A Channel, Airway Asm. 1 (incl. receptacle) (incl. receptacle) 1 24 53306A Sound Insulation Set 1 25 53214A Latch, Canister to Brush Hsg. 1 26 53274A Pin, Canister to Brush Hsg. 1 27 53319A Interconnect Cord (incl. #43) 1 28 53328A Spring, Air Valve 1 29 53240A Plunger, Spring 1 30 53264A Retainer, Air Valve 1 31 53252A Retainer, Tools 1 32 53220N Crevice Tool 1 33 53221N Upholstery Tool w/Brush 1 34 53262N Wand Assembly 1 35 53253A Handle, Cord Hook 1 36 53254N Swivel, Cord Hook 1 37 53255A Retainer, Hose 2 38 | | | | _ |
| 23 53256A Channel, Airway Asm. (incl. receptacle) 1 24 53306A Sound Insulation Set 1 25 53214A Latch, Canister to Brush Hsg. 1 26 53274A Pin, Canister to Brush Hsg. 1 27 53319A Interconnect Cord (incl. #43) 1 28 53328A Spring, Air Valve 1 29 53240A Plunger, Spring 1 30 53264A Retainer, Air Valve 1 31 53252A Retainer, Tools 1 32 53220N Crevice Tool 1 33 53221N Upholstery Tool w/Brush 1 34 53262N Wand Assembly 1 35 53253A Handle, Cord Hook 1 36 53254N Swivel, Cord Hook 1 37 53255A Retainer, Hose 2 38 53290N Clamp, Asm. Handle 1 (incl. 53210A & 53273A) 1 39 | | | | |
| 24 53306A Sound Insulation Set 1 25 53214A Latch, Canister to Brush Hsg. 1 26 53274A Pin, Canister to Brush Hsg. 1 27 53319A Interconnect Cord (incl. #43) 1 28 53328A Spring, Air Valve 1 29 53240A Plunger, Spring 1 30 53264A Retainer, Air Valve 1 31 53252A Retainer, Tools 1 32 53220N Crevice Tool 1 33 53221N Upholstery Tool w/Brush 1 34 53262N Wand Assembly 1 35 53253A Handle, Cord Hook 1 36 53254N Swivel, Cord Hook 1 37 53255A Retainer, Hose 2 38 53290N Clamp, Asm. Handle 1 (incl. 53210A & 53273A) 1 39 53253A Bag Full Indicator 1 | | | | |
| 24 53306A Sound Insulation Set 1 25 53214A Latch, Canister to Brush Hsg. 1 26 53274A Pin, Canister to Brush Hsg. 1 27 53319A Interconnect Cord (incl. #43) 1 28 53328A Spring, Air Valve 1 29 53240A Plunger, Spring 1 30 53264A Retainer, Air Valve 1 31 53252A Retainer, Tools 1 32 53220N Crevice Tool 1 33 53221N Upholstery Tool w/Brush 1 34 53262N Wand Assembly 1 35 53253A Handle, Cord Hook 1 36 53254N Swivel, Cord Hook 1 37 53255A Retainer, Hose 2 38 53290N Clamp, Asm. Handle 1 (incl. 53210A & 53273A) 1 39 53253A Bag Full Indicator 1 | 23 | 53256A | | 1 |
| 25 53214A Latch, Canister to Brush Hsg. 1 26 53274A Pin, Canister to Brush Hsg. 1 27 53319A Interconnect Cord (incl. #43) 1 28 53328A Spring, Air Valve 1 29 53240A Plunger, Spring 1 30 53264A Retainer, Air Valve 1 31 53252A Retainer, Tools 1 32 53220N Crevice Tool 1 33 53221N Upholstery Tool w/Brush 1 34 53262N Wand Assembly 1 35 53253A Handle, Cord Hook 1 36 53254N Swivel, Cord Hook 1 37 53255A Retainer, Hose 2 38 53290N Clamp, Asm. Handle 1 (incl. 53210A & 53273A) 1 39 53253A Bag Full Indicator 1 | | | | |
| 26 53274A Pin, Canister to Brush Hsg. 1 27 53319A Interconnect Cord (incl. #43) 1 28 53328A Spring, Air Valve 1 29 53240A Plunger, Spring 1 30 53264A Retainer, Air Valve 1 31 53252A Retainer, Tools 1 32 53220N Crevice Tool 1 33 53221N Upholstery Tool w/Brush 1 34 53262N Wand Assembly 1 35 53253A Handle, Cord Hook 1 36 53254N Swivel, Cord Hook 1 37 53255A Retainer, Hose 2 38 53290N Clamp, Asm. Handle 1 (incl. 53210A & 53273A) 1 39 53253A Bag Full Indicator 1 | | | | |
| 27 53319A Interconnect Cord (incl. #43) 1 28 53328A Spring, Air Valve 1 29 53240A Plunger, Spring 1 30 53264A Retainer, Air Valve 1 31 53252A Retainer, Tools 1 32 53220N Crevice Tool 1 33 53221N Upholstery Tool w/Brush 1 34 53262N Wand Assembly 1 35 53253A Handle, Cord Hook 1 36 53254N Swivel, Cord Hook 1 37 53255A Retainer, Hose 2 38 53290N Clamp, Asm. Handle 1 (incl. 53210A & 53273A) 1 39 53253A Bag Full Indicator 1 | | | | |
| 28 53328A Spring, Air Valve 1 29 53240A Plunger, Spring 1 30 53264A Retainer, Air Valve 1 31 53252A Retainer, Tools 1 32 53220N Crevice Tool 1 33 53221N Upholstery Tool w/Brush 1 34 53262N Wand Assembly 1 35 53253A Handle, Cord Hook 1 36 53254N Swivel, Cord Hook 1 37 53255A Retainer, Hose 2 38 53290N Clamp, Asm. Handle 1 (incl. 53210A & 53273A) 1 39 53253A Bag Full Indicator 1 | | | | |
| 29 53240A Plunger, Spring 1 30 53264A Retainer, Air Valve 1 31 53252A Retainer, Tools 1 32 53220N Crevice Tool 1 33 53221N Upholstery Tool w/Brush 1 34 53262N Wand Assembly 1 35 53253A Handle, Cord Hook 1 36 53254N Swivel, Cord Hook 1 37 53255A Retainer, Hose 2 38 53290N Clamp, Asm. Handle 1 (incl. 53210A & 53273A) 1 39 53253A Bag Full Indicator 1 | | | ` ' | |
| 30 53264A Retainer, Air Valve 1 31 53252A Retainer, Tools 1 32 53220N Crevice Tool 1 33 53221N Upholstery Tool w/Brush 1 34 53262N Wand Assembly 1 35 53253A Handle, Cord Hook 1 36 53254N Swivel, Cord Hook 1 37 53255A Retainer, Hose 2 38 53290N Clamp, Asm. Handle 1 (incl. 53210A & 53273A) 1 39 53253A Bag Full Indicator 1 | | | 1 0. | |
| 31 53252A Retainer, Tools 1 32 53220N Crevice Tool 1 33 53221N Upholstery Tool w/Brush 1 34 53262N Wand Assembly 1 35 53253A Handle, Cord Hook 1 36 53254N Swivel, Cord Hook 1 37 53255A Retainer, Hose 2 38 53290N Clamp, Asm. Handle 1 (incl. 53210A & 53273A) 39 53253A Bag Full Indicator 1 | | | | |
| 32 53220N Crevice Tool 1 33 53221N Upholstery Tool w/Brush 1 34 53262N Wand Assembly 1 35 53253A Handle, Cord Hook 1 36 53254N Swivel, Cord Hook 1 37 53255A Retainer, Hose 2 38 53290N Clamp, Asm. Handle 1 (incl. 53210A & 53273A) 39 53253A Bag Full Indicator 1 | | | | |
| 33 53221N Upholstery Tool w/Brush 1 34 53262N Wand Assembly 1 35 53253A Handle, Cord Hook 1 36 53254N Swivel, Cord Hook 1 37 53255A Retainer, Hose 2 38 53290N Clamp, Asm. Handle 1 (incl. 53210A & 53273A) 39 53253A Bag Full Indicator 1 | | | · · · · · · · · · · · · · · · · · · · | |
| 34 53262N Wand Assembly 1 35 53253A Handle, Cord Hook 1 36 53254N Swivel, Cord Hook 1 37 53255A Retainer, Hose 2 38 53290N Clamp, Asm. Handle 1 (incl. 53210A & 53273A) 39 53253A Bag Full Indicator 1 | | | | |
| 35 53253A Handle, Cord Hook 1 36 53254N Swivel, Cord Hook 1 37 53255A Retainer, Hose 2 38 53290N Clamp, Asm. Handle (incl. 53210A & 53273A) 1 39 53253A Bag Full Indicator 1 | | | | |
| 36 53254N Swivel, Cord Hook 1 37 53255A Retainer, Hose 2 38 53290N Clamp, Asm. Handle (incl. 53210A & 53273A) 1 39 53253A Bag Full Indicator 1 | | | | |
| 37 53255A Retainer, Hose 2 38 53290N Clamp, Asm. Handle (incl. 53210A & 53273A) 1 39 53253A Bag Full Indicator 1 | | | | |
| 38 53290N Clamp, Asm. Handle (incl. 53210A & 53273A) 1 39 53253A Bag Full Indicator 1 | | | | |
| (incl. 53210A & 53273A) 39 53253A Bag Full Indicator 1 | | | | |
| 39 53253A Bag Full Indicator 1 | " | 00200IN | | ' |
| 1 1 ° | 39 | 53253A | | 1 |
| 40 53225N Hose Assembly 1 | | 53225N | Hose Assembly | |

N.A.C.E. DM1400 & DM1800 Drawing #2 Brush Housing Assembly 3/04




N.A.C.E. DM1400 & DM1800

Parts List #2 Brush Housing Assembly 3/04

| Ref. | | | |
|------|----------|-------------------------------------|------|
| No. | Part No. | Description | Qty. |
| 1 | 53231N | Cover Asm., Brush Hsg. 14" | 1 |
| | 53232N | Cover Asm., Brush Hsg. 18" | 1 |
| 2 | | (cover asm. include #2) | |
| 3 | 53245A | Pedal, Brush Height | 1 |
| 4 | 53243A | Pivot Asm., Airway | 1 |
| | | (incl. 53236A, 53244A Bracket, | |
| | | Airway Right; & 53243A Bracket, | |
| | | Airway Left) | |
| 5 | | Cotter Pin | 2 |
| 6 | 53259N | Hub Cap | 2 |
| 7 | | Axle Hub | 2 |
| 8 | 53219A | Spacer, Rear Wheel | 4 |
| 9 | 53248A | Rear Wheel | 2 |
| 10 | 53227N | Brush Housing Asm. 14" | 1 |
| | 53228N | Brush Housing Asm. 18" | 1 |
| | | (incl. 53312A, 53313A, 53263A (18)) | |
| 11 | 53267A | Bumper 14" | 1 |
| | 53268A | Bumper 18" | 1 |
| 12 | 53331A | Spring, Brush Height Shaft | 1 |
| 13 | 53355A | E-clips M6 | 4 |
| 14 | 53284A | Guide, Brush Height Shaft | 1 |
| 15 | 53229A | Rollers | 3 |
| 16 | 53260A | Brush Assembly 14" | 1 |
| | 53261A | Brush Assembly 18" | 1 |
| 17 | 53250N | Bottom Plate 14" | 1 |
| | 53251N | Bottom Plate 18" | 1 |
| 18 | 53263A | Tension Lever | 2 |
| 19 | 53354A | Belt | 1 |
| 20 | 53350A | Screw, Flathead M4 x 15 | 2 |
| 21 | 53286A | Retainer, Door and Rollers | 1 |
| 22 | 53282A | Shaft, Rollers | 1 |
| 23 | 53230A | Cleanout Door Asm. | 1 |
| | | (incl. 53311A, 53278A & 53322A) | |
| 24 | | Screw, M58 x 24 | 2 |
| 25 | | Washer, M5 | 2 |
| 26 | 53348A | Screw, M47 x 10 | 2 |
| 27 | | Washer, M4 | 2 |
| 28 | 53285A | Bracket, Brush Motor | 1 |
| 29 | | Nuts, M58 | 2 |
| 30 | 53325A | Motor, Brush 120V | 1 |
| | | (incl. #26, 27, 28, 31 & 53298A) | |
| 31 | E00.151 | Endcap, Brush Motor | 1 |
| 32 | 53249A | Pedal, Foot Latch | 1 |
| 33 | 53326A | Circuit Board 120V | 1 |
| 34 | 53275A | Pin, Support Pivot | 1 |
| 35 | 53333A | Spring (include with #36) | 1 |
| 36 | 53241A | Support Asm., Canister Pivot | 1 |
| | 500004 | (includes #13, 34, 35) | , |
| 37 | 53293A | Rear Axle (includes #7) | 1 |

N.A.C.E. DM1400 & DM1800 Electrical Schematic 3/04



NOTES

NACECARE SOLUTIONS U.S. LIMITED WARRANTY

This N.A.C.E. Industrial/Commercial Product is warranted to be free from defects in materials and workmanship under normal use and service for a period of one year from the date of purchase, when operated and maintained in accordance with N.A.C.E. Maintenance and Operations instructions.

This brush drive and traverse motors are warranted to be free from defects in materials and workmanship under normal use and service for one year from the date of purchase, provided the motors are inspected for carbon motor brush wear at six-month intervals by an authorized N.A.C.E. service center. Failure to comply with the six-month inspection requirement or failure to replace worn motor brushes identified during the inspection will void the one-year warranty on the motors. Cost of the six-month inspection and replacement of carbon motor brushes is the responsibility of the purchaser. In the event of a warranty claim on the motors, proof of inspection and any required motor brush replacement must be provided.

This warranty is extended only to the original purchaser for use of the product. It does not cover normal wear parts such as electrical cable, rubber parts, and motor brushes.

N.A.C.E.'s liability under this warranty is limited to repair of the product and/or replacement of parts and is given to purchaser in lieu of all other remedies, including INCIDENTAL AND CONSEQUENTIAL DAMAGES.

THERE ARE NO EXPRESS WARRANTIES OTHER THAN THOSE SPECIFIED HEREIN. THERE ARE NO WARRANTIES WHICH EXTEND BEYOND THE DESCRIPTION OF THE FACE HEREOF. NO WARRANTIES, INCLUDING BUT NOT LIMITED TO WARRANTY OF MERCHANTABILITY. SHALL BE IMPLIED.

If a difficulty develops with the product, you should: a) Contact the nearest authorized N.A.C.E. service center or contact N.A.C.E., 1205 Britannia Road East Mississauga, Ontario, Canada for the nearest authorized N.A.C.E. service center. Only these locations are authorized to make repairs to the product under this warranty. (b) Return the product to the nearest N.A.C.E. Service Center. Transportation charges to and from the repair location must be prepaid by the purchaser. N.A.C.E. will repair the product and/or replace any defective parts with out charge within a reasonable time after receipt of the product.

NACECARE SOLUTIONS
reserves the right to make changes or
improvements to its
machine without notice.

1205 Britannia Road East Mississauga, Ontario, Canada L4W IC7

Tel: 905 795 0122 Toll Free: 1 800 387 3210 Fax: 1 800 709 2896